





Begin by installing the RV50 Cable into the back of the display either into Port C or port D. Once the Beacon is installed proceed to the Wrench and select GPS Receiver on the right, followed by Setup on the Left. On the GPS Receiver setup page change the Corrections to Centerpoint RTK.




Return to the Configuration page and select GPS receiver and Diagnostics (password 2009). Then Select Ag Remote.



### Ag Remote Setup instructions

1. Press the right arrow twice to configuration -> press the Down arrow to enter the Configuration menu -> Press the Right arrow until you get to the port D config -> Press the down arrow to enter.
2. Use the Right arrow once to select TSIP and the up or down arrows to change that to RTCM \*Confirm Baud rate is set to 38k4-> Press the Right arrow 5 More times to move to the Bottom TSIP and using up or down change this to NONE. Press enter (see screenshot below to confirm settings) -> Then down once -> Confirm MNEA1 has nothing capitalized, then proceed down to NMEA2 and confirm nothing is capitalized. Press the esc icon 3 times to return to the main screen.



**\*Note- If this unit was ordered with a subscription, it will be preprogrammed and plug and play ready. The following instruction**

Log into the device via WAN static IP (166.XXX.XXX.XXX:8080) or LAN connection (192.168.1.1:8080) on Port 8080 (shown in ip con-

The username and password to log into these devices are as follows

Username: digifarm

Password: digifarm

You will then be directed to the page shown below. On this page you can select a receiver preset based on the receiver type you have, then enter your username and password. Save device info at the bottom then select the reboot icon at the top of the screen

### DigiFarm: NTRIP Client Settings Manager

Logged in as: digifarm | [Log Out](#)

Presets

NovAtel (Raven: RS1, Cruiser II with RTK, 600s, Envizio Pro/Pro II, Viper 4)

Host

caster.godigifarm.com

Port

3101

Mount Point

VB\_N\_RTCM3\_NOV

Serial Port - Baud Rate

38400

Username

Password

Internal GPS

Manual GPS

Manual GPS - Latitude (Example: "4043.124436,N")

Manual GPS - Longitude (Example: "9640.586358,W")

[Save Changes](#)

### RV50 hardware Installation Guide

